NACHİ

REMOTE CONTROL PRESSURE REFIEF VALVE

Remote Control Relief Valve

2 to 15ℓ/min 21MPa



V P(V) V M L⊥T(DR)

Features

①Connecting a relief valve or reducing valve to the vent port of a balanced piston type pressure control valve provides simple remote control of pressure.


②RCD type can also be used as a direct type relief valve.

Specifications

	del No.	Nominal Diameter	Maximum Working Pressure	Maximum Flow Rate		
Screw Mounting	Gasket mounting	(Size)	MPa{kgf/cm ² }	ℓ/min	IVIFa{Kgi/CIII }	kg
RCD-T02-1-11 3-11	-	1/4	21 {214} P, V ports	15	0.8 to 7 { 8.2 to 71.4} 3.5 to 21 {35.7 to 214 }	2.1
RC-T02-1-12 3-12	RC-G02-1-21 3-21			2	0.8 to 7 { 8.2 to 71.4} 3.5 to 21 {35.7 to 214 }	1.4


Note) The pressure adjustment range indicates cracking pressure.


Explanation of model No.



Installation Dimension Drawings

RCD-T02-*-11 (Screw Mounting)





Handling


- To adjust pressure, loosen the lock nut and then rotate the handle clockwise (rightward) to increase pressure or counterclockwise (leftward) to decrease it.
- 2 Make sure that drain port back pressure is no greater than 0.2 MPa {2.0 kgf/cm²}.
- 3 When configuring pipes for the pressure control valve and remote control valve, use of thick iron pipe with an inside diameter of no more than 4mm and a connection length of no more than three meters is recommended. Pipe capacity can be a source of vibration.
- ^[4]When an adjustment bolt type is required for the pressure adjustment block, insert K for the type specification. See the dimension drawings, RC-G02 only.
- 5Use the following to specify a sub plate.

Model No.	Weight kg
MRC-02-20	1.0

⁶ The following are the bundled mounting bolts.

Model No.	Bolt Dimensions	Q'ty	Tightening Torque N·m{kgf·cm}
RC-G02-*-21	M8×25ł	4	20 to 25 {205 to 255}

Note) For mounting bolts, use bolts of 12.9 strength classification or equivalent.



F